



## **Assembly Guide for Outdoor Volleyball**

### **Identify parts**

- 1 x Winch post – with 4 holes and plastic plug in top
- 1 x Anchor post – with 3 holes and plastic plug in top
- 1 x Winch mounted on collar
- 1 x Collar with pulley attached to cleat
- 1 x Collar with shackle attached to cleat
- 2 x Plain collars with cleats only
- 1 x Winch cable with shackle attached
- 1 x Winch handle
- 1 x Winch instructions
- 2 x Ground sockets if ordered

### **Assembly**

#### **Ground Sockets**

- Mark out the position of the ground sockets to give the correct spacing between the posts to suit your net
- Install the ground sockets in concrete in suitably prepared holes following good trade practice – As a guide, the post holes should be a minimum of 450mm diameter x 500mm deep but this will need to be adjusted to suit local ground conditions.
- Sockets should be installed plumb and flush with the finished ground level

#### **Winch post**

- Hold the winch with the locking pawl at the top and slide it over the top of the winch post and use the bolt in the collar to fasten into the lowest hole.
  - Fit one of the plain collars over the top of the post and slide it down to just above the winch and use the 'T' bolt in the collar to tighten against the post.
- Note- this bolt does not go into a hole.



- Fit the collar with pulley over the top of the post and use the 'T' bolt in the collar and locate it in one of the 3 net height holes - Senior, Intermediate and Junior height.
- Pass the raw end of the winch cable over through the pulley, down the post and attach it to the drum of the winch following the winch instructions provided.
- Fit the handle to the winch

#### Anchor post

- Fit a plain collar over the top of the anchor post and tighten it about 1/3 way down the post.
- Fit the collar with the shackle over the top of the post and locate it in one of the 3 net height holes using the "T" handle

#### Set up

- Stand the posts in their ground sockets with the holes in the posts on the back of the posts facing out of court.
- Set both top collars to the net height required
- Attach one end of the steel cable in the head band of your net to the shackle on the top collar of the anchor post and attach the other end to the shackle on the winch cable.
- Note: The top net cable may need to be shortened as it is not unusual for them to be longer than is required. Please consult your net supplier for advice.
- Tension the net with the winch
- Adjust the lower plain collars as needed then tie on the lower net cords each side

**All sizes are nominal**

**Mayfield Sports Limited reserves the right to alter any specifications**